

# Pregis PolyMask Protective Film

## 31825



### Technical Data

February, 2019

**Product Description** Pregis PolyMask 31825 is a low adhesion temporary protection film designed for a variety of surface protection applications.

Product Construction	Backing	Adhesive	Color	Standard Roll Sizes
	Polyethylene	Acrylic-Based	Clear*	Custom

\* Contact your local Pregis PolyMask representative for additional information on colors.

**Typical Physical Properties** **Note: The following technical information and data should be considered representative or typical only, and should not be used for specification purposes.**

	Nominal Results	ASTM Test Method
Adhesion to Steel:	5 oz./in. width (1.37 N/25 mm)	D-3330**
Tensile:	2500 PSI	D-882**
Elongation:	450%	D-882**
Total Tape Thickness:	3 mils (0.08 mm)	D-3652**

\*\* ASTM test references modified per internal test methods.

- Features**
- Effective in many outdoor applications for up to 3 days.
  - Surface protection against dust, dirt and moderate abrasion encountered in handling, shipping and storage.
  - Transparent backing with Pregis PolyMask proprietary adhesive works for a wide variety of applications offering excellent contact clarity, quick adhesion, repositionable and smooth removal.
  - Good conformability for hand and machine applied applications.
  - Backing designed for good stamping and die cutting.

- Application Ideas**
- **General** – smooth semi-gloss cultured marble, high pressure laminates.
  - **Metals** – 2B #3 and #4 finish stainless steel.
  - **Painted** – smooth semi-gloss.
  - **Plastics** – smooth semi-gloss.

# Pregis PolyMask Protective Film

31825



<b>Application / Removal Techniques</b>	<ul style="list-style-type: none"><li>• For optimum performance, Pregis PolyMask Protective Films should be applied and removed at a temperature not less than 60°F (16°C).</li><li>• Surfaces should be dry and free from dirt, oil and other contaminants when film is applied.</li><li>• Protective film should be removed gradually beginning from one edge with a smooth even motion.</li></ul>
<b>Storage</b>	Store under normal conditions of 60° to 80°F (16° to 27°C) and 40 to 60% R.H in the original carton.
<b>Shelf Life</b>	To obtain best performance, use this product within 12 months from date of manufacture.
<b>For Additional Information</b>	To request additional product information or to arrange for sales assistance, call toll free 1-844-232-6783. Address correspondence to: Pregis PolyMask, 500 Thornburg Dr., Conover, NC 28613.
<b>Technical Information</b>	The technical information, recommendations and other statements contained in this document are based upon tests or experience that Pregis PolyMask believes are reliable, but the accuracy or completeness of such information is not guaranteed.
<b>Product Use</b>	Many factors beyond Pregis PolyMask’s control and uniquely within user’s knowledge and control can affect the use and performance of a Pregis PolyMask product in a particular application. Given the variety of factors that can affect the use and performance of a Pregis PolyMask product, user is solely responsible for evaluating the Pregis PolyMask product and determining whether it is fit for a particular purpose and suitable for user’s method of application.
<b>Warranty and Limited Remedy</b>	Unless an additional warranty is specifically stated on the applicable Pregis PolyMask product packaging or product literature, Pregis PolyMask warrants that each Pregis PolyMask product meets the applicable Pregis PolyMask product specification at the time Pregis PolyMask ships the product. Pregis PolyMask MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If the Pregis PolyMask product does not conform to this warranty, then the sole and exclusive remedy is, at Pregis PolyMask’s option, replacement of the Pregis PolyMask product or refund of the purchase price.
<b>Terms and Conditions</b>	<u><a href="http://www.pregis.com/pregis-polymask-terms-and-conditions/">Our standard Terms &amp; Conditions as available on http://www.pregis.com/pregis-polymask-terms-and-conditions/ apply to all transactions, quotations, test reports and other communication.</a></u>
<b>Limitation of Liability</b>	Except where prohibited by law, Pregis PolyMask will not be liable for any loss or damage arising from the Pregis PolyMask product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.



This product was manufactured under a quality system registered to ISO 9001 standards by Pregis